

Guarantee

All our Terra Nova and Wild Country products are guaranteed to the original owner against defects in materials and workmanship.

In order to take advantage of this guarantee, your purchase must be registered with us using the online registration form at www.terra-nova.co.uk.

In the event of a fault with your purchase, please contact your retailer or our Customer Services department, or refer to our website.

We will either repair defects free of charge or replace your product at our sole discretion. The guarantee excludes damage caused by wear and tear, including weathering, Ultra Violet degradation, storm damage, misuse, neglect or accident.

This guarantee is a "back to base" guarantee and does not include the costs of returning the product to us.

This guarantee does not affect your statutory rights.

Terra Nova Equipment Ltd
Summit House Salcombe Court Salcombe Road Meadow Lane Industrial Estate
Alfreton Derbyshire DE55 7EG UK
Tel: +44 (0) 1773 837373 Fax: +44 (0) 1773 831088

TERRA



NOVA
EQUIPMENT

WILD



COUNTRY
by Terra Nova

OWNERS MANUAL



T E R R A



N O V A
E Q U I P M E N T

W I L D



C O U N T R Y
by Terra Nova

Thank you for choosing to buy one of our tents, and we hope you have many happy adventures with it. To help with this, we have provided you with this Owners Manual, with advice on the use and care of your tent.

Contents

- 1 General pitching advice
- 2 Cooking in our tents
- 3 Condensation management
- 4 Fabrics
- 5 Seams
- 6 UV light degradation
- 7 Poles
- 8 Which eyelet do I use?
- 9 Zips
- 10 Extended use
- 11 Storage
- 12 Servicing
- 13 Cleaning
- 14 Repairs
- 15 Spares
- 16 Accessories

1

General pitching advice

Practice pitching your tent before using it for the first time.

Clear the site of stones and twigs and if possible use a Groundsheet Protector. Groundsheet Protectors (purchased separately) or 'footprints' provide extra protection from sharp objects and rough ground, and help prolong the life of the tent's groundsheet. Groundsheet Protectors are cut precisely to fit under the inner tent(s) of each model.

It is not advisable to wear boots inside the tent. Try to ensure that nothing sharp or abrasive is pushed against the groundsheet inside the tent.

Pitch the tent with the back into wind and use natural shelter (hedges, walls etc) where possible.

Choose a level, sheltered site that is well drained.

Sap is almost impossible to remove from flysheet fabric, so avoid pitching under trees.

Always ensure that everything is pegged or weighted down, including the flysheet awaiting assembly.

Once pitched leave the doors closed as much as possible since they increase the strength and stability of the tent. Never leave the doors open if you are away from the tent, particularly on windy days.

2

Cooking in our tents

Our advice is 'do not cook in our tents, or porch areas'. Our tents are not guaranteed against fire damage, or associated heat damage from cooking such as hot fat etc. In addition cooking can lead to a build up of dangerous combustion gasses, such as Carbon Monoxide. If you **must** cook inside the porch, make sure you maintain the maximum distance possible between stove and flysheet or inner and ensure maximum ventilation.



If you have to pitch an inner-first model in the rain, we would advise covering the pegged down inner with the flysheet whilst you thread the poles. If conditions prevent this, the speed with which you can pitch a Terra Nova tent (with practice) will minimise the exposure of the inner to the rain. Inner tents have a DWR treatment to enable any water that reaches the inner tent to bead and roll away.

All tents are supplied with sufficient pegs required for pitching. Additional pegs, or a different design of peg may be required in heavy or unusual pitching conditions.

Always use all the guylines on the flysheet. Guylines contribute to the overall strength of the tent, increasing its stability and performance in bad weather. Failure to use guylines correctly may result in damage to the tent.

3

Condensation management

Condensation occurs in all tents.

The amount of condensation will vary depending on the prevailing conditions, from water only apparent on touching the inside of the tent to droplets extending over the whole upper canopy.

Single skin tents and bivi bags will suffer more from condensation than conventional tents. Tents fitted with snow valances are also likely to suffer more due to reduced air flow. A person can produce more than one litre of perspiration in a single night, so maximising ventilation is the key to reducing condensation.

On still, dry nights, leave the flysheet doors open as much as possible. In more adverse conditions, create a small tunnel vent at the top of the door by unzipping the flysheet doors approximately 15cm. The pole sleeves are designed to aid air flow between the tent inner and flysheet. On windy, dry nights, it should be possible to have no condensation at all if the tent is well ventilated, as the action of the wind on the flysheet pumps out the damp air. In freezing conditions condensation can form as hoarfrost inside the tent. Again, prevention by maximum ventilation is the answer.

Generally, the best method of dealing with heavy condensation, assuming dry conditions in the morning, is to remove the flysheet, shake off condensation and replace it. If the condensation is slight and conditions are windy, simply venting the tent will soon dry out the flysheet.

4

Fabrics

During prolonged heavy rain the nylon fibres in the flysheet fabric will absorb some of the water and expand. This will give the flysheet a wet appearance in places – wetting out – and may cause it to sag slightly. If this occurs it is important to re-tension the flysheet by adjusting the pole feet from the outer most to inner most eyelet on the webbing tapes. After the rain has stopped and the flysheet starts to dry out, the nylon fibres will contract. It is important to loosen the flysheet tension by re adjusting the pole feet to the outer most eyelets on the webbing tapes. If the tension is not released, in some cases, the force of the contracting flysheet can damage the poles.

Cleaning and reproofing the outer surface with Terra Nova Tent Cleaner and Tent re-proofer can help stop water from building up in the fibres and causing the effects of wetting out.

5

Seams

Some Terra Nova models use Silicon coatings on both faces of the flysheet fabric. In these models it is not possible to factory seam tape the seam. Best efforts are made through design and position of these seams to ensure that water does not leak through these points. To make certain that water does not leak through these seams, we recommend that you apply a seam sealer such as Silnet by Mcnett to the exterior of the seams on these models. If you are unsure to which tent model this relates, please either contact your retailer, check our web site, or give us a call on 01773 837373.

6

UV light degradation

Exposure to strong sunlight causes damage to all tent fabrics, resulting in the fabric losing strength. This is normal wear and tear. The lighter fabrics are more susceptible to UV damage. High altitude exposure causes much more rapid degradation. Preventing early deterioration from UV exposure depends entirely on how the tent is used. Where possible, pack the tent away to reduce exposure, and use tents with heavier fabrics in base camp situations.

7

Poles

Always ensure that all pole sections are fully connected. Poles that take up tight curves when tensioned are pre-bent at the factory, but poles that start out straight will take a curve during use. This is normal and should cause you no concern.

DO NOT “snap” or “throw” the poles into place because this may damage the pole and lead to the pole splitting or breaking.

DO NOT force the poles. Poles are put under some of the greatest tension during pitching and many of us do not realise our own strength! If the pole sleeve is gathered, gently ease out the gathers over the pole as you thread it. To release tension open the doors.

When collapsing your poles for packing, always start by folding the pole from the middle as this ensures an even stretch in the shockcord. Do not allow the sections to flick back against each other under the elastic tension, as this can cause damage to the section ends.

Always ensure that the poles are stored dry. Dampness assists corrosion which can lead to pole breakage.

If corrosion has occurred, clean off with a cloth and re-lubricate with our Zip Lube. Do not use oil or grease as this will attract dirt. Periodic lubrication should be undertaken, even if corrosion has not taken place.

All aluminium alloys will corrode if exposed to a salt water environment, even sea spray. Wash them thoroughly in clean water, dry them and lubricate. This may be necessary even if camping some distance from the shore.

If a pole breaks under exceptional conditions or through accident, use the pole repair sleeve which is provided with each lightweight and endurance tent (not included with Superlite models or the Wild Country range), to effect a temporary repair. Cover the break in the pole with the sleeve and tape it in place. Additional repair sleeves can be purchased separately.

Replacement poles are available from Terra Nova. If you are going overseas for an extended expedition it is worth taking spare poles in case of breakage. You may also want to consider taking an extra set of poles to double pole your tent if you are travelling to an exposed area (double poling is not possible on some models, please contact your retailer or call us on 01773 837373 if you have any questions).

Do not force anything. If you have to use excessive force when pitching something is wrong. Stop and loosen any points of tension such as straps and zips, as continuing may risk damaging the tent.

8

Which eyelet should I use?

During normal conditions, insert the poles in the outer most eyelets on the webbing tape. This will make it easier to line up the flysheet seams with their corresponding poles. Peg out the groundsheet, using the webbing tapes, applying tension evenly.

9

Zips

We use the very best loop coil zips throughout all of our tents. In normal use they will give trouble free performance. However, periodic lubrication with Zip Lube will ensure that this high performance continues.

Dusty conditions or contamination with mud will cause the zips to lose performance and stick. If the zips become fouled DO NOT FORCE THEM, as you will damage the teeth. Clean with soapy water, rinse and re-lubricate with Zip Lube.

If the zips on your tent fail, it is probably because the slider is worn. We can replace sliders or complete zips.



10

Extended use

If you are fortunate enough to go on an extended trip where the tent will have prolonged use **BE PREPARED**.

We strongly recommend:

- Using a Groundsheet Protector.
- Taking spare pole(s) in case of breakage or considering double poling the tent if traveling to an exposed area.
- Periodically using zip and pole lube to lubricate zips.
- Taking an Emergency Repair Kit.

Remember weather conditions can be unpredictable, and no tent is infallible.



11

Storage

After using your tent, it is worthwhile spending time checking it over on your return. Look for signs of wear and tear which may require attention. Early detection may prevent problems developing later. Most importantly, check that the tent and poles are dry, re-lubricating zips and poles as necessary. Remember, eyelet tapes take longer to dry than the tent fabric, and dampness (which can cause mildew) may be trapped in the folds of the tent when stored.

If the tent or bivi bag is stored wet for long periods, water can react with certain chemicals in the seam tape, causing the tape to lift, coating to breakdown and eventually decompose. If mildew occurs (identified by black marks and a mouldy smell), sponge the affected areas with a mild solution of disinfectant, then sponge with soapy water, rinse and dry thoroughly. (DO NOT USE DETERGENTS) If not caught early enough, permanent damage to fabric and proofing will occur.

Do not store your tent or bivi bag near sources of heat, remember lofts and garages can become very warm during summer months. Periodically air your tent to prevent the fabrics from adhering to each other and affecting the performance of the tent.

Store your tent in a cool dry place and never dry it in direct heat.

12

Tent servicing

We offer a full repairs service to cope with the damage that wear and tear and regular use can cause. If you need repair work to be carried out, return your tent to us in a clean and dry condition*. Please enclose a clear description of the damage. It would be helpful if you could indicate on the tent the location of any damage. Our Customer Services staff will examine the damage and send you a quote for the necessary repairs. We will endeavour to return your repaired tent to you within 15 working days of receiving your go ahead (at busy times of the year April-August it may take longer).

A returns form and address label is available on our website www.terra-nova.co.uk/Customer_Services

**Health and Safety regulations mean we can only accept products in a clean and dry condition.*

13

Cleaning

We recommend that you regularly use tent cleaner or pure soap to clean your tent or bivi bag.

Wash your tent or bivi in the bath or a tub of warm water. Always rinse out and dry thoroughly in the shade.

If camping near salt water, wash in clean water or better still in tent cleaner.

After cleaning, reproofing the outer will improve its water repellancy. It is better to use a re proofer with a built in UV protector if you can.



- DO NOT use detergents to clean your tent as they may harm the proofing
- NEVER machine wash or tumble dry your tents
- AVOID contact with fuel, oil and chemicals, as the stains from these may be impossible to remove and will probably attack the fabric and damage the proofing
- AVOID pitching under trees as sap may fall onto the flysheet and it is almost impossible to remove.

If you are not happy cleaning your own tent or simply do not have the time, we now offer a tent cleaning service.

Call 01773 837387 or look on www.terra-nova.co.uk for details.

14

Repairs

Even with the best care possible, accidents and general wear and tear will occur. However, we can usually repair your tent, even if the damage is extensive.

Field repairs – Use duck tape / gaffer tape or a needle and thread, to repair tears when out in the field. Use a synthetic adhesive such as cycle puncture repair glue with the fabric swatches provided (glue is not provided with the tent). Poles can be temporarily repaired using the pole repair sleeve (provided on some Terra Nova tents) – cover the pole with the sleeve and then tape it in place. A more comprehensive Emergency Repair Kit is available (see Accessories 16).

15

Spares

Terra Nova maintain a comprehensive stock of spare parts for our tents, including some discontinued models. Please contact our Customer Services department for details:

Customer Services +44 (0)1773 837387

Or go online www.terra-nova.co.uk

16

Accessories

A comprehensive range of items designed to add greater versatility and performance to the tents, available from your local stockist or direct from Terra Nova.

Groundsheet Protectors

Tailor-made for each tent in the range, these provide extra protection from sharp objects and rough ground, and help to increase the life of the tent's groundsheet.

The Loft

Suitable for the Terra Nova Endurance tents in our range and any tent with hanging loops, The Loft is an ideal way of increasing storage space. Designed to clip to the binding near the apex of the inner tent, it is quick and easy to fit and offers 2 mesh storage pockets and a torch loop.

Emergency Repair Kit

The Emergency Repair Kit contains fabrics, adhesive, guylines inc sliders and pole repair sleeve in a neat pack.

Tent Cleaner

For use on all our flysheets and inners, Tent Cleaner will clean the fabric without impairing breathability or waterproofness.

Tent proofer

Spray on treatment for tent flysheets. Re-proofs the fabric and helps reduce UV damage with a built in inhibitor. Use our Tent Cleaner first for maximum effect.

Zip Lube

Zip Lube is a silicone-based spray for lubricating and protecting tents zips, aluminium alloy poles and metal components.

Pegs

We provide a comprehensive range of pegs, from snow stakes to 1g titanium pegs. Check out our website for the full range.

Valances

When long periods of exposure to extreme winter conditions are expected, consider adding snow valances to your tent. We can fit these at our factory to Endurance range models and the Ultra Quasar. Please call our customer services department on 01773 837387 for further details.

To find further information about our range, supported expeditions and awards, check out our website www.terra-nova.co.uk. Sign up to our newsletter if you would like to be kept up to date about new products, magazine reviews, expedition news and competitions.